

Allstarlink-DV2fm-settings-guide

Show FM node in Allstarlink Supremo dashboard

← → ↻ ⚠ Not Secure 192.168.2.30/supermon/link.php?nodes=592030

Your CALL – Supermon 6.1+ (ASL) AllStar Manager
Logout
Edit /var/www/html/supermon/global.inc to change!
RPi2-3-4 Node
AllStar/IRLP/Echolink System Manager

592030 1999 1888 All Nodes IsNodes AllStarLink

Permanent ☐

Connect Disconnect Monitor Local Monitor DTMF Lookup Rpt Stats Bubble Chart Control Favorites

Configuration Editor lax/Rpt/DP RELOAD AST START AST STOP RESTART Server REBOOT

AllStar How To's AllStar Wiki CPU Status AllStar Status Node Info Active Nodes All Nodes

GPIO Linux Log AST Log Connection Log Web Access Log Web Error Log Restrict

[pi-star] [WAN IP: 183.23.58.129] [WLAN IP: 192.168.2.30] [AstP: 4569] [MgrP: 5038] [SShP: 22]
[Wednesday, July 15, 2026 HKT 00:32:22 up 1 min, 1 user, load average: 1.99, 0.82, 0.30]

Display Configuration [CPU: 100°F, 38°C @ 00:32]

[Weather conditions for Edit /var/www/html/supermon/global.inc to change! 93301: No Report]

Private Node 592030 => Node not in database IsNodes						
Node	Node Information	Received	Link	Direction	Connected	Mode
592030	Idle					
1888	Node not in database	Never	ESTABLISHED	IN	00:03:23	Transceive
1998	Node not in database	Never	ESTABLISHED	IN	00:03:23	Transceive
1999	Node not in database	Never	ESTABLISHED	IN	00:03:23	Transceive
46007	Node not in database	Never	ESTABLISHED	IN	00:03:23	Transceive

/


System maintained by: Your NAME, Your CALL

Config Template


<https://www.bi7jta.org/files/Allstarlink-sip/astrisk-configV2/>

rpt.conf

simpleusb.conf




Edit in J-Star Menu




Download J-Star for Raspberry 4B/3B

<https://github.com/JTA-STAR/J-STAR/blob/main/README.md>



Detail setting guide for Allstarlink in J-Star

Discord: <https://discord.gg/ukxVSjWHU> (Join first)



Contact me :

https://wiki.bi7jta.org/wiki/index.php?title=Main_Page#Contact_me_Now

DE BI7JTA
VY 73